




COMPONENTS











Method for positioning carriages and hinge recesses

The drawing below shows an alternative method (when it is not possible to cut Ø35 mm openings in the aluminium profiles)





Combining two sets of DS LINE right + left



The assembly of folding doors **SECRET LINE** and **SLIM LINE** opened to the right and to the left side requires the use of two sets:

- 1. Set LINE (right side)
- 2. Set LINE (left side)

Calculations for the combination of the sets right + left:

