

Height 84 mm

Sevrollbox Slim drawer system – assembly instructions



<p>Components</p> <p>ATTENTION! screws are not included</p>	<p>Cutting dimensions of 16 mm MDF</p> <p>Back panel B LW - 87 mm 68</p> <p>Base panel A NL - 7 mm LW - 75 mm</p> <p>NL: 270 (mm) 300 350 400 450 500 550</p> <p>A - Base panel B - Back panel</p> <p>LW - internal cabin width NL - nominal length of drawer</p>	<p>Drawer front regulation</p> <p>Side adjustment within ± 1.5 mm</p> <p>Height adjustment within ± 2 mm</p> <p>Locking</p>
---	---	---

<p>Installation measurement</p> <p>min. 115 110 min. 33 min. 49</p>	<p>Mounting dimensions for drawer front panel</p> <p>15.5 32 min. 47.5</p> <p>To precisely drill your holes we recommend using Sevroll templates: - for assembly of drawer front mounts (5338) - for assembly of drawer guides (5337)</p>	<p>Mounting dimensions of back panel</p> <p>9 20 32</p>	<p>Cover insertion / removal</p>	<p>Drawer front panel removal</p> <p>When releasing the drawer front be sure rotate the bolts in the correct direction</p> <p>1 2</p>
---	---	---	----------------------------------	---

<p>Drawer runner positioning</p> <p>Slide NL: 270, 300, 350, 400, 450</p> <p>Slide NL: 500, 550</p> <p>Minimal depth of cabinet: (NL + 3 mm)</p> <p>224, 256, 37, 37, 37 mm</p> <p>Drawerbox with front installed</p> <p>Drawer front installed</p> <p>NL: 270 (mm) 300 350 400 450 500 550</p> <p>Warning: in drawers with recessed fronts, the guides should be positioned further back by the thickness of the drawer front!</p>	<p>Drawer insertion</p> <p>1 2 "Click"</p>	<p>Additionally: For ease of assembly (especially with full overlay fronts) you can withdraw the slides. Hold in the highlighted position and use the release catches.</p> <p>"Click"</p>
---	--	---

<p>Drawer assembly</p> <p>1 2 3 4 5 6</p> <p>If you find the drawer base panel is loose when fitted to the drawer sides, you can pack the fixing points with washers</p>	<p>Drawer removal</p> <p>1 2 release slides drawer removal</p>	<p>Drawer strengthening</p> <p>A B 8 mm >600 mm</p> <p>We recommend additional reinforcement for drawers with a width greater than 600 mm: A - screw the bottom of the drawer to the drawer back using three 3.5x30 screws B - screwing the bottom of the drawer to the drawer front using steel bracket (40343) and 3.5x13 screws</p>
--	--	---