

Height 90* / 131** / 178*** / 213**** mm

SEVROLLBOX SLIM 3D drawer system – assembly instructions



Attention! * Dimensions for 90 mm drawer / ** Dimensions for 131 mm drawer / *** Dimensions for 178 mm drawer / **** Dimensions for 213 mm drawer

Components

ATTENTION!
screws are not included

Cutting dimensions of 16 mm MDF

NL : 270 [mm]
300
350
400
450
500
550

A – Base panel
B – Back panel

LW – internal cabin width
NL – nominal length of drawer

Drawer assembly

Drawer runner positioning

Minimal depth of cabinet: (NL + 3 mm)

Drawer front installed

Installation measurement

Warning:
in drawers with recessed fronts,
the guides should
be positioned
further back by the
thickness of the
drawer front!

D - Positioning of drawer front

Drawer front regulation

Side adjustment within ±1.5 mm

Height adjustment within ±2 mm

Locking

Rear height adjustment within ±2 mm

Mounting dimensions for drawer front panel

D - Positioning of drawer front

Drawer front 90 mm*

Drawer front 131mm**

Drawer front 178 mm***

Drawer front 213 mm****

Mounting dimensions of back panel

Back panel for 90 mm sides*

Back panel for 131 mm sides**

Back panel for 178 mm sides***

Back panel for 213 mm sides****

Drawer removal

Drawer strengthening

>600 mm

We recommend additional reinforcement for drawers with a width greater than 600 mm by screwing the bottom of the drawer to the drawer front using steel bracket (40343) and 3.5x13 screws.