



## 1. Installation of pull down clothes rail arms Remove the cover plate from pull down clothes rail arm Screw the pull down clothes rail arms to carcass sides (1), replace cover plates (2) 1 G 2

