



LINE


Minicomfort

SYSTEM







COMFORT 18



SEVROLL®




## COMPONENTS



With Minicomfort set you may use bottom track **Doubler II** with covering strip along with bottom carriage WD18V HI-TEC. Fitting measurements are not affected.

**Option: bottom track DOUBLER II**





LINE

Minicomfort


SYSTEM

COMFORT 18



SEVROLL®

## Dimensions of opening




Handle length = door height

door height	- h	$h = H - 42 \text{ mm}$	
door wing height with soft-close fitted	Mini SV25/40/60, SV-25/50	$h = H - 42 \text{ mm}$	
	Top SV60/80, Central SV25/40	$h = H - 44 \text{ mm}$	
board height	- hb	$hb = h - 2 \text{ mm}$	
door width	- w	$w = (W - 3 \text{ mm} + Z) : N$	
board width #18	- wb	$wb = w - 7 \text{ mm}$	
angle section length	- la	this size is determined after door construction	

number of doors	- N	2	3	4	5
total overlap	- Z	20 mm	40 mm	60 mm	80 mm


visual design – 4 wings	
	$w = (W - 3 + 60) : 4$
	$w = (W : 2 + 17) : 2$

**ATTENTION!**



Handle profile should be 2 mm longer than board height.

- When fitting handle profiles, do not use assembly adhesive

Installation method for handle and guiding carriage with # 18 mm board (handle Comfort # 18 mm)



Installation method for angle section Mini 11 mm x 17 mm

**WARNING**

SEVROLL does not bear any responsibility for deformation resulting from the application of improper quality of boards (improper storage, improper humidity)

**ATTENTION!**

Remove protective film from aluminium elements (handles, tracks, connectors, etc.) prior to cutting them to the desired size. Film removal will reveal quality issues (eg. scratches)