




LINE

VICTORIA / GEMINI 18







SYSTEM




SEVROLL®




COMPONENTS

<p>Handle VICTORIA II C</p> <p>L: 2.70 m</p> <p>anti-dust brushes (self-adhesive) 6.7 mm x 13 mm</p> <p>textile door stop (inserted) 4.8 mm x 4 mm</p> <p>#16, #18</p> 	<p>Top track Gemini-Decor</p> <p>L: 1.70 m, 2.35 m, 3.00 m, 4.05 m, 6.00 m</p>  <p>76 mm</p>	<p>Bottom track Gemini-Decor II</p> <p>L: 1.70 m, 2.35 m, 3.00 m, 4.05 m, 6.00 m</p>  <p>53 mm</p>
<p>Guiding carriage Focus</p> 	<p>Angle section K2 Decor</p> <p>L: 1.70 m, 2.35 m, 3.00 m</p> 	<p>Bottom carriage WD18C HI-TEC</p> 

With **VICTORIA** set you may also use bottom track **Elegant II** with **covering strip** along with bottom carriage **WD 18V HI-TEC**. **Fitting measurements are not affected.**



Stopper **HI-TEC**





LINE

VICTORIA / SYSTEM


SYSTEM

GEMINI 18



SEVROLL®

Dimensions of opening




Handle length = door height

door height	- h	$h = H - 42 \text{ mm}$
door wing height with soft-close fitted	Mini SV25/40/60 SV-25/50	$h = H - 42 \text{ mm}$
	Top SV60/80, Central SV25/40	$h = H - 44 \text{ mm}$
board height	- hb	$hb = h - 2 \text{ mm}$
door width	- w	$w = (W - 3 \text{ mm} + Z) : N$
board width #18	- wb	$wb = w - 22 \text{ mm}$
board width #12	- wb _m	$wb_m = w - 7 \text{ mm}$
angle section length	- la	$la = w - 48.4 \text{ mm}$

number of doors - N	2	3	4	5
total overlap - Z	36 mm	72 mm	108 mm	144 mm

visual design – 4 wings

	$w = (W - 3 + 108) : 4$
	$w = (W : 2 + 33) : 2$




mirror dimension

mirror height - hm = hb - 4 mm


mirror width - wm = wb_m - 20 mm**ATTENTION:**

Board to mirror contact area should be free from dirt and grease before applying double-sided tape.

Broken line indicates recommended positioning of double-sided tape




Installation method for handle and guiding carriage with # 18 mm board




- When fitting handle profiles, do not use assembly adhesive
- The handle should be fixed to board with fastening screws $\text{Ø}3 \times 13$ on the inner door face


Installation method for handle and guiding carriage with # 12 mm board + # 4 mm mirror

jeżeli płyta lub lustro nie trzymają wymiarów i rączka jest zbyt luźno osadzona, należy ją przykręcić do płyty wkrętami $\text{Ø}3 \times 10$.**Wkręty dostępne w ofercie Sevroll-System**

Installation method for angle section K2 Decor

**ATTENTION!**

Angle section must be fastened to board with minimum 3 screws 3 x 25



assembly adhesive (this is necessary when using mirror)

ATTENTION!

Handle profile should be 2 mm longer than board height.

WARNING

SEVROLL does not bear any responsibility for deformation resulting from the application of improper quality of boards (improper storage, improper humidity)

ATTENTION!

Remove protective film from aluminium elements (handles, tracks, connectors, etc.) prior to cutting them to the desired size. Film removal will reveal quality issues (eg. scratches)