




LINE

MINICOMFORT / SYSTEM

COMFORT 18



SEVROLL



COMPONENTS

Handle MiniComfort II L: 2.70 m textile door stop (inserted) 4.8 mm x 4 mm # 18 mm	Top track Comfort-Decor L: 1.70 m, 2.35 m, 3.00 m, 4.05 m, 6.00 m 94 mm	Bottom track Comfort L: 1.70 m, 2.35 m, 3.00 m, 4.05 m, 6.00 m 62 mm
Guiding carriage Comfort	Angle section Mini L: 1.70 m, 2.35 m, 3.00 m 11 mm x 17 mm	Bottom carriage WD18C HI-TEC

With Minicomfort set you may use bottom track **Doubler II** with covering strip along with bottom carriage WD18V HI-TEC. Fitting measurements are not affected.





LINE


MINICOMFORT /

SYSTEM

COMFORT 18

SEVROLL

Dimensions of opening




Handle length = door height

door height	- h	$h = H - 42 \text{ mm}$	
door wing height with soft-close fitted	Mini SV25/40/60, SV-25/50	$h = H - 42 \text{ mm}$	
	Top SV60/80, Central SV25/40	$h = H - 44 \text{ mm}$	
board height	- hb	$hb = h - 2 \text{ mm}$	
door width	- w	$w = (W - 3 \text{ mm} + Z) : N$	
board width #18	- wb	$wb = w - 7 \text{ mm}$	
angle section length	- la	this size is determined after door construction	

number of doors	- N	2	3	4	5
total overlap	- Z	20 mm	40 mm	60 mm	80 mm

visual design – 4 wings	
	$w = (W - 3 + 60) : 4$
	$w = (W : 2 + 17) : 2$




ATTENTION!


Handle profile should be 2 mm longer than board height.

- When fitting handle profiles, do not use assembly adhesive

Installation method for handle and guiding carriage with # 18 mm board (handle Comfort # 18 mm)



Installation method for angle section Mini 11 mm x 17 mm



WARNING

SEVROLL does not bear any responsibility for deformation resulting from the application of improper quality of boards (improper storage, improper humidity)

ATTENTION!

Remove protective film from aluminium elements (handles, tracks, connectors, etc.) prior to cutting them to the desired size. Film removal will reveal quality issues (eg. scratches)