




LINIA



Comfort / SYSTEM COMFORT 18



## COMPONENTS

<p>Handle Comfort II</p> <p>textile door stop (inserted) 4.8 mm x 4 mm</p> <p>anti-dust brush (self-adhesive) 6.7 mm x 13 mm #16 i #18</p> <p>Length 2.7 m</p>	<p>Top track Comfort Decor</p> <p>94 mm</p> <p>Length 1.7 m, 2.35 m, 3.0 m, 4.05 m, 6.0 m</p>	<p>Bottom track Comfort</p> <p>62 mm</p> <p>Length 1.7 m, 2.35 m, 3.0 m, 4.05 m, 6.0 m</p>
<p>Giding carriage Comfort WPCm-Duo</p>	<p>Angle section ZW</p> <p>20 mm x 18 mm</p> <p>Length 1.7 m, 2.35 m, 3.0 m</p>	<p>Bottom carriage WD 18 C HI-TEC</p>

With Comfort set you may use bottom track **Doabler II** with covering strip along with bottom carriage WD18V HI-TEC. Fitting measurements are not affected.





LINIA


Comfort / SYSTEM

SYSTEM

COMFORT 18



Dimensions of opening




Handle length = door height

door height	- h	$h = H - 42 \text{ mm}$
door wing height with soft-close fitted	Mini SV25/40/60, SV-25/50	$h = H - 42 \text{ mm}$
	Top SV60/80, Central SV25/40	$h = H - 44 \text{ mm}$
board height	- hb	$hb = h - 2 \text{ mm}$
door width	- w	$w = (W - 3 \text{ mm} + Z) : N$
board width #18	- wb	$wb = w - 7 \text{ mm}$
board width #12	- wb <sub>m</sub>	$wb_m = w - 7 \text{ mm}$
angle section length	- la	this size is determined after door construction

number of doors - N	2	3	4	5
total overlap - Z	35 mm	70 mm	105 mm	140 mm

visual design – 4 wings

	$w = (W - 3 + 105) : 4$
	$w = (W : 2 + 32) : 2$




mirror dimensions

mirror height - hm	$hm = hb - 4 \text{ mm}$
mirror width - wm	$wm = wb_m - 34 \text{ mm}$


**ATTENTION:**  
board to mirror contact area should be free from dirt and grase before applying double-sided tape

Broken line indicates recommended positioning of double-sided tape




- When fitting handle profiles, do not use assembly adhesive
- The handle should be fixed to board with fastening screws on the inner door face



Installation method for handle and guiding carriage with # 18 mm board (handle Comfort # 18 mm)



Installation method for handle and guiding carriage with # 12 mm board + # 4 mm mirror (handle Comfort # 16 mm)



Installation method for angle section 20 mm x 18 mm

**ATTENTION!**

Angle section must be fastened to board with minimum 3 screws  $\varnothing 3 \times 25$ .

**ATTENTION!**

Handle profile should be 2 mm longer than board height.

**WARNING**

SEVROLL does not bear any responsibility for deformation resulting from the application of improper quality of boards (improper storage, improper humidity)

**ATTENTION!**

Remove protective film from aluminium elements (handles, tracks, connectors, etc.) prior to cutting them to the desired size. Film removal will reveal quality issues (eg. scratches)