


## COMPONENTS

<p><b>Handle Comfort II</b></p> <p>L: 2.70 m</p> <p>textile door stop (inserted) 4.8 mm x 4 mm</p> <p>anti-dust brush (self-adhesive) 6.7 mm x 13 mm</p> <p>#16, #18</p>	<p><b>Top track Comfort-Decor</b></p> <p>L: 1.70 m, 2.35 m, 3.00 m, 4.05 m, 6.00 m</p> <p>94 mm</p>	<p><b>Bottom track Comfort</b></p> <p>L: 1.70 m, 2.35 m, 3.00 m, 4.05 m, 6.00 m</p> <p>62 mm</p>
<p><b>Guiding carriage Comfort</b></p>	<p><b>Angle section ZW</b></p> <p>L: 1.70 m, 2.35 m, 3.00 m</p> <p>20 mm x 18 mm</p>	<p><b>Bottom carriage WD 18C HI-TEC</b></p>






LINE

**COMFORT / SYSTEM**

SYSTEM

**COMFORT 18****SEVROLL®**

Dimensions of opening




Handle length = door height

door height	- h	$h = H - 42 \text{ mm}$
door wing height with soft-close fitted	Mini SV25/40/60, SV-25/50	$h = H - 42 \text{ mm}$
	Top SV60/80, Central SV25/40	$h = H - 44 \text{ mm}$
board height	- hb	$hb = h - 2 \text{ mm}$
door width	- w	$w = (W - 3 \text{ mm} + Z) : N$
board width #18	- wb	$wb = w - 7 \text{ mm}$
board width #12	- $wb_m$	$wb_m = w - 7 \text{ mm}$
angle section length	- la	this size is determined after door construction

number of doors	- N	2	3	4	5
total overlap	- Z	35 mm	70 mm	105 mm	140 mm

visual design – 4 wings

	$w = (W - 3 + 105) : 4$
	$w = (W : 2 + 32) : 2$




mirror dimensions

mirror height	- $hm = hb - 4 \text{ mm}$
mirror width	- $wm = wb_m - 34 \text{ mm}$


**ATTENTION:**  
board to mirror contact area should be free from dirt and grase before applying double-sided tape

Broken line indicates recommended positioning of double-sided tape




- When fitting handle profiles, do not use assembly adhesive
- The handle should be fixed to board with fastening screws on the inner door face



Installation method for handle and guiding carriage with # 18 mm board (handle Comfort # 18 mm)



Installation method for handle and guiding carriage with # 12 mm board + # 4 mm mirror (handle Comfort # 16 mm)



Installation method for angle section 20 mm x 18 mm

**ATTENTION!**

Angle section must be fastened to board with minimum 3 screws  $\varnothing 3 \times 25$ .

**ATTENTION!**

**Handle profile should be 2 mm longer than board height.**

**WARNING**

**SEVROLL does not bear any responsibility for deformation resulting from the application of improper quality of boards (improper storage, improper humidity)**

**ATTENTION!**

Remove protective film from aluminium elements (handles, tracks, connectors, etc.) prior to cutting them to the desired size. Film removal will reveal quality issues (eg. scratches)