


Dimensions of opening




Handle length = door height

door height		- h	h = H - 42 mm		
door wing height with soft-close fitted		Mini SV25/40/60, SV-25/50		h = H - 42 mm	
		Top SV	60/80, SV25/40	h = H - 44 mm	
board height		- hb	hb = h - 2 mm		
door width		- W	w = (W - 3 mm + Z) : N		
board width	#18	- wb	wb = w - 7 mm		
angle section length		- la	this size is determined after door construction		

number of doors	- N	2	3	4	5
total overlap	- Z	20 mm	40 mm	60 mm	80 mm

visual design – 4 wings				
door set up	w = (W - 3 + 60) : 4			
door set up	w = (W : 2 + 17) : 2			




ATTENTION! -


Handle profile should be 2 mm longer than board height.


- When fitting handle profiles, do not use assembly adhesive

Installation method for handle and guiding carriage with # 18 mm board (handle Comfort # 18 mm)



Installation method for angle section Mini 11 mm x 17 mm





WARNING –

SEVROLL does not bear any responsibility for deformation resulting from the application of improper quality of boards (improper storage, improper humidity)