




SYSTEM









SHAKER / LINE



SEVROLL®



COMPONENTS

Handle Shaker  textile door stop (inserted) 14 mm x 4 mm	Top track Shaker  76 mm	Bottom track Shaker  49 mm	Covering strip Shaker 	H10 profile Shaker 
Guiding carriage Gemini 	Lower horizontal profile Shaker (A) Upper horizontal profile Shaker (B) 	Bottom carriage WD10V HI-TEC 	<p>You must remember to purchase self-tapping screws to construct each door (4 screws per door). When using safety glass, you must also remember to purchase gaskets.</p>	




SYSTEM

SHAKER / LINE



SEVROLL®

Dimensions of opening



door filling:
board # 10 mm
mirror or safety glass # 4 mm


handle length = door height

door height	- h	$h = H - 40 \text{ mm}$	
door wing height with soft-close fitted		Mini SV40/60, SV-25/50	$h = H - 40 \text{ mm}$
		Top SV60/80, Central SV-40	$h = H - 44 \text{ mm}$
board height	- hb	$hb = h - 64 \text{ mm}$	
door width	- w	$w = (W - 3 \text{ mm} + Z) : N$	
board width	- wb	$wb = w - 71 \text{ mm}$	
lower horizontal profile length	- L	$L = U = w - 88 \text{ mm}$	
upper horizontal profile length	- U		
mirror height	- hm	$hm = hb$	
mirror wigth	- wm	$wm = wb - 4 \text{ mm}$	

number of doors	- N	2	3	4	5
total overlap	- Z	45 mm	90 mm	135 mm	180 mm


visual design - 4 wings

	$w = (W - 3 + 135) : 4$
	$w = (W : 2 + 42) : 2$




Installation method for fitting 10 mm board (diag. A) and 4 mm mirror or glass (diag. B)

- with handle




- with upper profile



construction clearance included in the calculation of the height of board

- with lower profile



ATTENTION!

Mirror (4 mm) should be used with a safety backing film. Safety glass (4.5 mm) comprises of two thin layers with a film in-between. Both mirror and glass need fitting gasket.