







door filling:

10 mm board, # 4 mm mirror or # 4.5 mm safety glass




Installation method for fitting 10 mm board (diag. A) and 4 mm mirror or glass (diag. B)

- with handle



- with upper profile





construction clearance included in the calculation of the height of board


Handle length = door height

door height	- h	h = H - 40 mm		
door wing height with soft-close fitted	Mini SV25/40/60, SV-25/50		h = H - 40 mm	
	Top SV6 Central		h = H - 44 mm	
board height	- hb	hb = h - 64 mm		
door width	- W	w = (W - 3 mm + Z) : N		
board width	- wb	wb = w - 20 mm		
lower horizontal profile length - L upper horizontal profile length - U		L = U = w - 37 mm		
mirror height	- hm	hm = hb		
mirror width	- wm	wm :	= wb - 4 mm	


number of doors	- N	2	3	4	5
total overlap	- Z	36 mm	72 mm	108 mm	144 mm







- with lower profile



ATTENTION!

Mirror (4 mm) should be used with a safety backing film. Safety glass (4.5 mm) comprises of two thin layers with a film in-between. Both mirror and glass need fitting gaskets.