



Option: bottom track **ELEGANT II**

## COMPONENTS



With Pax set you may also use bottom track **Elegant II** with covering strip along with bottom carriage **WD10V HI-TEC**. Fitting measurements are not affected.



You must remember to purchase self-tapping screws to construct each door (4 screws per door).



LINE

Pax / SYSTEM

SYSTEM

GEMINI 4




SEVROLL®

door filling:

- mirror # 4 mm,  
coloured glass

Dimensions of opening




Handle length = door height

Door height	- h	$h = H - 40 \text{ mm}$
Door wing height with soft-close fitted	Mini SV25/40/60, SV-25/50	$h = H - 40 \text{ mm}$
	Top SV60/80, Central SV25/40	$h = H - 44 \text{ mm}$
Mirror height	- hm	$hm = h - 4 \text{ mm}$
Door width	- w	$w = (W - 3 \text{ mm} + Z) : N$
Mirror width	- wm	$wm = w - 4 \text{ mm}$
Lower horizontal profile length	- L	$L = U = S = w - 50 \text{ mm}$
Upper horizontal profile length	- U	
Strengthening profile length	- S	
Spacer profile 04 length		$S + 46 \text{ mm}$

Number of doors	- N	2	3	4	5
Total overlap	- Z	25 mm	50 mm	75 mm	100 mm

Visual design - 4 wings


	$w = (W - 3 + 75) : 4$
	$w = (W : 2 + 22) : 2$



It is recommended to use  
soft-close with system PAX XL!


**Installation method for fitting  
mirror or coloured glass 4 mm**

- with handle




- with upper profile



- with lower profile



- with strengthening profile



it is recommended that mirror /  
coloured glass is glued to aluminium profiles  
with specialist glass adhesive

The method of cutting  
spacer profile 04**ATTENTION!**

Rear mirror / coloured glass surface must  
be secured with safety backing foil.  
The edges of glass must be polished.

**ATTENTION!**

Remove protective film from aluminium elements (handles, tracks, connectors, etc.) prior to cutting them to the desired size. Film removal will reveal quality issues (eg. scratches)