

COMPONENTS

Handle

L: 2.70 m, 3.00 m L: 2.70 m

MASTER **STAR**

Lower horizontal profile Decor (A)

Upper horizontal profile Decor (B)

L: 1.70 m, 2.35 m, 3.00 m L: 1.70 m, 2.35 m, 3.00 m

Top track TOP

L: 1.70 m, 2.35 m, 3.00 m, 6.00 m

48

Bottom carriage WD10V HI-TEC

Guiding carriage MASTER

DEPENDENT ON FLOOR TYPE, YOU MAY CHOOSE FROM DIFFERENT BOTTOM TRACKS

Bottom track HIDE M insert

L: 1.70 m, 2.35 m, 3.00 m, 6.00 m

Bottom track HIDE G to be used with tiles

L: 1.70 m, 2.35 m, 3.00 m, 6.00 m

Bottom track HIDE W II to be used with carpet

L: 3.00 m, 6.00 m


Bottom track HIDE N surface mounted

L: 1.70 m, 2.35 m, 3.00 m, 6.00 m



To dolny montażowy Hide M

L: 1.70 m, 2.35 m, 3.00 m, 6.00 m


You must remember to purchase self-tapping screws to construct each door (4 screws per door). When using safety glass, you must also remember to purchase gaskets.



		Handle length = door height			
		LINE MASTER		LINE STAR	
		Handle Master	Guiding carriage Master	Handle Star	Guiding carriage Master
Dimensions of opening					
Track HIDE N door height	- h	$h = H - 40 \text{ mm}$		$h = H - 40 \text{ mm}$	
door wing height with soft-close fitted		Mini SV25/40/60 SV-25/50	$h = H - 40 \text{ mm}$	Mini SV25/40/60 SV-25/50	$h = H - 40 \text{ mm}$
	Track HIDE N	Top SV60/80 Central SV25/40	$h = H - 44 \text{ mm}$	Top SV60/80 Central SV25/40	$h = H - 44 \text{ mm}$
Track HIDE W II door height	- h	$h = H - 42 \text{ mm}$		$h = H - 42 \text{ mm}$	
door wing height with soft-close fitted		Mini SV25/40/60 SV-25/50	$h = H - 42 \text{ mm}$	Mini SV25/40/60 SV-25/50	$h = H - 42 \text{ mm}$
	Track HIDE W II	Top SV60/80 Central SV25/40	$h = H - 46 \text{ mm}$	Top SV60/80 Central SV25/40	$h = H - 46 \text{ mm}$
Tracks HIDE: M, G , track seat HIDE M door height	- h	$h = H - 35 \text{ mm}$		$h = H - 35 \text{ mm}$	
door wing height with soft-close fitted		Mini SV25/40/60 SV-25/50	$h = H - 35 \text{ mm}$	Mini SV25/40/60 SV-25/50	$h = H - 35 \text{ mm}$
	HIDE M, HIDE G , track seat HIDE M	Top SV60/80 Central SV25/40	$h = H - 39 \text{ mm}$	Top SV60/80 Central SV25/40	$h = H - 39 \text{ mm}$
board height	- hb	$hb = h - 64 \text{ mm}$		$hb = h - 64 \text{ mm}$	
assumed door width	- w	w		w	
board width	- wb	$wb = w - 25 \text{ mm}$		$wb = w - 40 \text{ mm}$	
lower horizontal profile length - L		$L = U = w - 42 \text{ mm}$		$L = U = w - 57 \text{ mm}$	
upper horizontal profile length - U					
mirror height	- hm	$hm = hb$		$hm = hb$	
mirror width	- wm	$wm = wb - 4 \text{ mm}$		$wm = wb - 4 \text{ mm}$	



Installation method for fitting 10 mm board (diag. A) and 4 mm mirror or glass (diag. B)



ATTENTION!

Mirror (4 mm) should be used with a safety backing film. Safety glass (4.5 mm) comprises of two thin layers with a film in-between. Both mirror and glass need fitting gaskets U.

ATTENTION!

Remove protective film from aluminium elements (handles, tracks, connectors, etc.) prior to cutting them to the desired size. Film removal will reveal quality issues (eg. scratches)