




Dimensions of opening




Handle length = door height

door height	- h	h = 1	H - 40 mm	
door wing height	Mini SV25/40/60, SV-25/50		h = H - 40 mm	
with soft-close fitted	Top SV60/80, Central SV25/40		h = H - 44 mm	
board height	- hb	hb = h - 64 mm		
door width	- W	w = (W - 3 mm + Z) : N		
board width	- wb	wb =	w - 40 mm	
horizontal profile length upper horizontal profile lengt	- L h <i>-</i> U	L = U	= w - 57 mm	

number of doors	- N	2	3	4	5
total overlap	- Z	30 mm	60 mm	90 mm	120 mm

visual design – 4 wings		
door set up	w = (W - 3 + 90) : 4	
door set up	w = (W : 2 + 27) : 2	




door filling - glass or mirror # 4 mm


mirror height - hm	hm = hb
mirror width - wm	wm = wb - 4 mm

Installation method for fitting 10 mm board (diag. A) and 4 mm mirror or glass (diag. B)


- with handle



- with upper profile



- with lower profile



ATTENTION!

Mirror (4 mm) should be used with a safety backing film. Safety glass (4.5 mm) comprises of two thin layers with a film in-between. Both mirror and glass need fitting gaskets.