



## COMPONENTS



With **Comfort**  
set you may use  
bottom track **Doubler II**  
**with covering strip**  
along with bottom carriage  
WD18V HI-TEC.  
**Fitting measurements**  
**are not affected.**



### Fastening of bottom track

Stopper  
**HI-TEC**



LINE


COMFORT /

SYSTEM

COMFORT 18

SEVROLL

Dimensions of opening




Handle length = door height

door height	- h	$h = H - 42 \text{ mm}$
door wing height with soft-close fitted	Mini SV25/40/60, SV-25/50	$h = H - 42 \text{ mm}$
	Top SV60/80, Central SV25/40	$h = H - 44 \text{ mm}$
board height	- hb	$hb = h - 2 \text{ mm}$
door width	- w	$w = (W - 3 \text{ mm} + Z) : N$
board width #18	- wb	$wb = w - 7 \text{ mm}$
board width #12	- wb <sub>m</sub>	$wb_m = w - 7 \text{ mm}$
angle section length	- la	this size is determined after door construction

number of doors	- N	2	3	4	5
total overlap	- Z	35 mm	70 mm	105 mm	140 mm

visual design – 4 wings

	$w = (W - 3 + 105) : 4$
	$w = (W : 2 + 32) : 2$




mirror dimensions

mirror height	- hm = hb - 4 mm
mirror width	- wm = wb <sub>m</sub> - 34 mm


**ATTENTION:**  
board to mirror contact area  
should be free from dirt  
and grase before applying  
double-sided tape

Broken line indicates recommended  
positioning of double-sided tape




- When fitting handle profiles, do not use assembly adhesive
- The handle should be fixed to board with fastening screws on the inner door face



Installation method for handle and guiding carriage with # 18 mm board (handle Comfort # 18 mm)



Installation method for handle and guiding carriage with # 12 mm board + # 4 mm mirror (handle Comfort # 16 mm)



Installation method for angle section 20 mm x 18 mm

**ATTENTION!**

Angle section must be fastened to board with minimum 3 screws Ø 3 x 25.

**ATTENTION!**

Handle profile should be 2 mm longer than board height.

**WARNING**

SEVROLL does not bear any responsibility for deformation resulting from the application of improper quality of boards (improper storage, improper humidity)

**ATTENTION!**

Remove protective film from aluminium elements (handles, tracks, connectors, etc.) prior to cutting them to the desired size. Film removal will reveal quality issues (eg. scratches)