

COMPONENTS


| | | |
|---|--|-----------------------------------|
| <p>Handle LYNX</p> <p>textile door stop (inserted) 14 mm x 4 mm</p> | <p>Top track SINGLE</p> | <p>Top carriage GEMINI</p> |
| <p>Lower horizontal profile Decor (A)</p> <p>Upper horizontal profile Decor (B)</p> | <p>Bottom carriage WD10V HI-TEC</p> | |

DEPENDENT ON FLOOR TYPE, YOU MAY CHOOSE FROM DIFFERENT BOTTOM TRACKS

| | | |
|---|---|---|
| <p>Bottom track HIDE M insert</p> | <p>Bottom track HIDE G to be used with tiles</p> | <p>Bottom track HIDE W II to be used with carpet</p> |
| <p>Bottom track HIDE N surface mounted</p> | <p>Track seat HIDE M</p> | |

You must remember to purchase self-tapping screws to construct each door (4 screws per door). When using safety glass, you must also remember to purchase gaskets.

Dimensions of opening





Handle length = door height



door filling – #10 mm board

Installation method for fitting 10 mm board (diag. A) and 4 mm mirror or glass (diag. B)

| | | |
|--|------------------------------|-----------------------------|
| Track HIDE N door height | - h | $h = H - 40 \text{ mm}$ |
| door wing height with soft-close fitted <i>Track HIDE N</i> | Mini SV25/40/60, SV-25/50 | $h = H - 40 \text{ mm}$ |
| | Top SV60/80, Central SV25/40 | $h = H - 44 \text{ mm}$ |
| Track HIDE W door height | - h | $h = H - 42 \text{ mm}$ |
| door wing height with soft-close fitted <i>Track HIDE W</i> | Mini SV25/40/60, SV-25/50 | $h = H - 42 \text{ mm}$ |
| | Top SV60/80, Central SV25/40 | $h = H - 46 \text{ mm}$ |
| Track HIDE M, HIDE G, track seat HIDE M door height | - h | $h = H - 35 \text{ mm}$ |
| door wing height with soft-close fitted <i>HIDE M, HIDE G</i> | Mini SV25/40/60, SV-25/50 | $h = H - 35 \text{ mm}$ |
| | Top SV60/80, Central SV25/40 | $h = H - 39 \text{ mm}$ |
| board height | - hb | $hb = h - 64 \text{ mm}$ |
| assumed door width | | w |
| board width | - wb | $wb = w - 41 \text{ mm}$ |
| lower horizontal profile length | - L | $L = U = w - 58 \text{ mm}$ |
| upper horizontal profile length | - U | |



construction clearance included in the calculation of the height of board



door filling - # 4 mm mirror or #4.5 mm safety glass

| | | |
|---------------|------|--------------------------|
| mirror height | - hm | $hm = hb$ |
| mirror width | - wm | $wm = wb - 4 \text{ mm}$ |

ATTENTION!
Mirror (4 mm) should be used with a safety backing film. Safety glass (4.5 mm) comprises of two thin layers with a film in-between. Both mirror and glass need fitting gaskets.

ATTENTION! Remove protective film from aluminium elements (handles, tracks, connectors, etc.) prior to cutting them to the desired size. Film removal will reveal quality issues (eg. scratches)