



LINE


UNIVERSAL

SYSTEM

GEMINI 18 EVEREST



SEVROLL®



ATTENTION!!!

System GEMINI 18 EVEREST is designed for use with a minimum of three door wings

COMPONENTS

Handle Universal C

L.: 2.70 m

anti-dust brushes (self-adhesive) 6.7 mm x 9 mm

textile door stop (inserted) 4.8 mm x 4 mm

#16, #18

Top track Gemini-Decor

L: 1.70 m, 2.35 m, 3.00 m, 4.05 m, 6.00 m

76 mm

Track Everest

L: 3.00 m

39

Bottom track Elegant II (A)

Covering strip Elegant II (B)

L: 1.70 m, 2.35 m, 3.00 m, 4.05 m, 6.00 m

A

B

Angle section ZW

L: 1.70 m, 2.35 m, 3.00 m

20 mm x 18 mm

Guiding carriage Focus

Bottom carriage WD18V HI-TEC

Guiding carriage Everest

L

R



LINE

UNIVERSAL


SYSTEM

GEMINI 18 EVEREST



SEVROLL®

Dimensions of opening



L - length of track Everest

 $W_a \geq X$ $L_{min.} = \frac{2}{3}W$



X - length of angle section

 $L_{max.} = W$ W_a - width of the wing with angle section

door height	- h	$h = H - 42 \text{ mm}$	
board height	- hb	$hb = h - 2 \text{ mm}$	
door width	- w	$w = (W - 3 \text{ mm} + Z) : N$	
board width	#12, #18 - wb	$wb = w - 7 \text{ mm}$	
angle section mini length	- la	$la = w - 62.4 \text{ mm}$	

number of doors	- N	3	4	visual design - 4 wings
total overlap	- Z	64 mm	96 mm	

door set up




mirror dimension


mirror height - $h_m = hb - 4 \text{ mm}$ mirror width - $w_m = wb - 4 \text{ mm}$ **ATTENTION:**

Board to mirror contact area should be free from dirt and grease before applying double-sided tape.


Broken line indicates recommended positioning of double-sided tape





Installation method for handle and guiding carriage with # 18 mm board (handle UNIVERSAL C # 18 mm)



Installation method for handle and guiding carriage with # 12 mm board and # 4 mm mirror (handle UNIVERSAL C # 16 mm)



Installation method for angle-section 20 mm x 18 mm



assembly adhesive (this is necessary when using mirror)

ATTENTION!

Angle section must be fastened to board with a minimum of 3 screws 3 x 25.

ATTENTION!

Remove protective film from aluminium elements (handles, tracks, connectors, etc.) prior to cutting them to the desired size. Film removal will reveal quality issues (eg. scratches)