



COMPONENTS







Dimensions of opening




door filling - 18 mm board

length of C-profile top/bottom	- Lz and Lw	determined after door construction
board width	- wb	wb = w - 24 mm
door width	- W	w = (W - 12 mm) : 2
board height	- hb	hb = h - 2 mm
door height	- h	h = H - 48 mm

W W wb wb Lw Lz

ATTENTION! -


Handle PRINCE 01 should be mounted on the hinged wing.




14 cuts in boards for top carriage and male pivot hinges


14 38 38 hb hb wb ii wb wing with wing with carriage hinges


Doors opening on the right or left side.




Method for inserting ABS strip into profiles







Top track Exclusive



When fixing hinges, doors should be touching one another. Do not use textile door stop in between the touching handles!