


Dimensions of opening




door filling - # 16 mm or # 18 board

Handle length = door height

door height	- h	h = H - 42 mm		
door wing Mini S Note: SV-25		SV25/40/60, 5/50	h = H - 42 mm	
soft-close fitted		V60/80, al SV25/40	h = H - 44 mm	
board height	- hb	hb = h - 2 mm		
door width	- W	w = (W - 3 mm + Z) : N		
board width	- wb	wb = w - 7 mm		
angle section length	- la	la = w - 57.8 mm		

number of doors	- N	2	3	4	5
total overlap	- Z	30 mm	60 mm	90 mm	120 mm

visual design – 4 wings				
door set up	w = (W - 3 + 90) : 4			
door set up	w = (W : 2 + 27) : 2			




ATTENTION! -

Handle profile should be 2 mm longer than board height.


- When fitting handle profiles, do not use assembly adhesive

Installation method for handle and guiding carriage with # 16 mm or # 18 mm board



Installation method for angle section K2 Decor





WARNING

SEVROLL does not bear any responsibility for deformation resulting from the application of improper quality of boards (improper storage, improper humidity)