


**ATTENTION:**  
In order to drill handle holes precisely and quickly, we recommend using our drill jig  
index 20173



**COMPONENTS**

Handle	
L: 2.70 m 3.50 m	L: 2.70 m 3.00 m
FUTURE II	MASTER

Horizontal profile Decor 10 (A)	
Upper horizontal profile Decor 10 (B)	
L: 1.70 m 2.35 m 3.00 m	L: 1.70 m 2.35 m 3.00 m


Guiding carriage
FUTURE or MASTER


Bottom carriage WD10C HI-TEC

Top track Comfort-Decor
L: 1.70 m, 2.35 m, 3.00 m, 4.05 m, 6.00 m
94 mm

Bottom track Comfort
L: 1.70 m, 2.35 m, 3.00 m, 4.05 m, 6.00 m
62 mm

You must remember to purchase self-tapping screws to construct each door (4 screws per door). When using safety glass or mirror, you must also remember to purchase gasket.







		Handle length = door height			
		LINE FUTURE		LINE MASTER	
		<b>Handle Future II</b> anti-dust brush (inserted) 4.8 mm x 13 mm 	<b>Guiding carriage FUTURE</b> 	<b>Handle Master</b> 	<b>Guiding carriage MASTER</b> L/R 
door height	- h	h = H - 40 mm		h = H - 40 mm	
door wing height with soft-close fitted		Mini SV25/40/60 SV-25/50	h = H - 40 mm	Mini SV25/40/60 SV-25/50	h = H - 40 mm
		Top SV60/80, Central SV25/40	h = H - 44 mm	Top SV60/80, Central SV25/40	h = H - 44 mm
board height	- hb	hp = h - 64 mm		hp = h - 64 mm	
door width	- w	d = (D - 3 mm + Z) : N		d = (D - 3 mm + Z) : N	
board width	- wb	dp = d - 51 mm		dp = d - 25 mm	
horizontal profile length	- L	P = G = d - 68 mm		P = G = d - 42 mm	
upper horizontal profile length	- U				
mirror height	- hl	hl = hp		hl = hp	
mirror width	- wl	dl = dp - 4 mm		dl = dp - 4 mm	

number of doors	- N	2	3	4	5	2	3	4	5
total overlap	- Z	37 mm	74 mm	111 mm	148 mm	22 mm	44 mm	66 mm	88 mm

visual design – 4 wings		
	$d = (D - 3 + 111) : 4$	$d = (D - 3 + 66) : 4$
	$d = (D : 2 + 34) : 2$	$d = (D : 2 + 19) : 2$



Installation method for fitting 10 mm board (diag. A) and 4 mm mirror or glass (diag. B)



**ATTENTION!**

Mirror (4 mm) should be used with a safety backing film. Safety glass (4.5 mm) comprises of two thin layers with a film in-between. Both mirror and glass need fitting gaskets U.

**ATTENTION!**

Remove protective film from aluminium elements (handles, tracks, connectors, etc.) prior to cutting them to the desired size. Film removal will reveal quality issues (eg. scratches)