















# Drawer front Set for the internal drawer PLATINIUM-18 4D






**SEVROLL®**

## Components:

<div>Drawer PLATINIUM-18 4D SLIM and PLATINIUM 4D glass sides <b>h = 96 / h = 134 / h = 181 mm</b></div> <div><div>Length: 250 [mm] 270 300 350 400 450 500 550 600</div></div>	<div>Drawer front base profile for internal drawer PLATINIUM SLIM for height:</div> <table><tr><th><b>h = 134</b></th><th><b>h = 96 i h = 181</b></th></tr><tr><td></td><td></td></tr></table>	<b>h = 134</b>	<b>h = 96 i h = 181</b>			<div>Universal drawer front railing for internal drawer PLATINIUM SLIM</div> <div></div> <div>Only for use with PLATINIUM SLIM 4D <b>h = 134 mm and h = 181 mm</b></div>
<b>h = 134</b>	<b>h = 96 i h = 181</b>					
						

<p>Set for internal drawer PLATINIUM SLIM <b>h = 96 mm</b></p>  <p>Screws for "drawer front base profile"</p>	<p>Set for internal drawer PLATINIUM SLIM <b>h = 134 mm</b></p>  <p>Screws for "drawer front base profile"</p>	<p>Set for internal drawer PLATINIUM SLIM <b>h = 181 mm</b></p>  <p>Screws for "drawer front base profile"</p>
--	--	---

Cutting dimensions of profiles		
 <p>NL : 250 [mm] 270 300 350 400 450 500 550 600</p> <p>LW – internal width of carcass NL – nominal length of the drawer</p>	<p>Drawer front base profile</p>  <p><math>L_p = LW - 137 \text{ mm}</math></p>	<p>Universal drawer front railing</p>  <p><math>L_r = LW - 126 \text{ mm}</math></p>
<p>Calculations for the back wall and base of the drawer can be found in the instructions PLATINIUM-18 4D SLIM</p>		

Mounting dimensions		
ATTENTION: * dimensions for drawers <b>PLATINIUM 4D</b> / ** dimensions for drawers <b>PLATINIUM 4D PUSH</b>		
<p><b>PLATINIUM SLIM 4D</b> <b>H = 96 mm</b></p>  <p>min. 115* / 119** min. 111* / 115** min. 25.5* / 29** min. 37.5* / 41**</p>	<p><b>PLATINIUM SLIM 4D</b> <b>H = 134 mm</b></p>  <p>min. 155* / 159** min. 149* / 153** min. 25.5* / 29** min. 37.5* / 41**</p>	<p><b>PLATINIUM SLIM 4D</b> <b>H = 181 mm</b></p>  <p>min. 205* / 209** min. 196* / 200** min. 25.5* / 29** min. 37.5* / 41**</p>
<p>minimum carcass length: (NL + 5 mm)* / (NL + 14 mm)**</p>  <p>Drawer with flush front</p> <p>37* 37**</p> <p>The front of the drawer sits level with the carcass edges</p>	<p>minimum carcass length: (NL + 14 mm)* / (NL + 23 mm)**</p>  <p>Drawer with inset front</p> <p>9 mm</p> <p>37* 37**</p> <p><b>ATTENTION!</b> To ensure that the drawers cover the high front applied, the slides should be taken back by 9 mm (one hole in the slide) into the carcass</p>	
(If the drawer is fitted with LED lights, an additional space for activating the off switch must be taken into consideration)		

Drawer front Set

for the internal drawer PLATINIUM-18 4D

The front of the internal drawer h = 96	The front of the internal drawer h = 134	The front of the internal drawer h = 181
Installing the drawer front for PLATINIUM SLIM h = 96 mm		
<div>1</div>	<div>2</div>	<div>3</div>
Installing the drawer front for PLATINIUM SLIM h = 134 mm and h = 181 mm		
<div>1</div>	<div>2</div>	<div>3</div>
Fixing the internal drawer front to base with support connector		
<div>4</div>	<div>5</div>	