

You must remember to purchase self-tapping screws to construct each door (4 screws per door). When using safety glass, you must also remember to purchase gaskets.



LINE


PORTO 18 GM, PROSPER 18 GM

SYSTEM

GEMINI 18



SEVROLL®



Handle length = door height


LINE PORTO GM




Guiding carriage Gemini



LINE PROSPER GM



Guiding carriage Gemini





door height	- h	$h = H - 40 \text{ mm}$		$h = H - 40 \text{ mm}$	
door wing height with soft-close fitted		Mini SV25/40/60 SV-25/50	$h = H - 40 \text{ mm}$	Mini SV25/40/60 SV-25/50	$h = H - 40 \text{ mm}$
		Top SV60/80, Central SV25/40	$h = H - 44 \text{ mm}$	Top SV60/80, Central SV25/40	$h = H - 44 \text{ mm}$
board height	- hb	$hb = h - 64 \text{ mm}$		$hb = h - 64 \text{ mm}$	
door width	- w	$w = (W - 3 \text{ mm} + Z) : N$		$w = (W - 3 \text{ mm} + Z) : N$	
board width	- wb	$wb = w - 41 \text{ mm}$		$wb = w - 31 \text{ mm}$	
lower horizontal profile length - L		$L = U = w - 58 \text{ mm}$		$L = U = w - 48 \text{ mm}$	
upper horizontal profile length - U					
mirror height	- hm	$hm = hb$		$hm = hb$	
mirror width	- wm	$wm = wb - 4 \text{ mm}$		$wm = wb - 4 \text{ mm}$	

number of doors	- N	2	3	4	5	2	3	4	5
total overlap	- Z	30 mm	60 mm	90 mm	120 mm	25 mm	50 mm	75 mm	100 mm

visual design – 4 wings

 door set up	$w = (W - 3 + 90) : 4$	$w = (W - 3 + 75) : 4$
 door set up	$w = (W : 2 + 27) : 2$	$w = (W : 2 + 22) : 2$




Installation method for fitting 18 mm board (diag. A) and 4 mm mirror or glass (diag. B)

- with handle

- with upper profile

- with lower profile



ATTENTION!

Remove protective film from aluminium elements (handles, tracks, connectors, etc.) prior to cutting them to the desired size. Film removal will reveal quality issues (eg. scratches)



LINE


ARTE 18 GM



SYSTEM

GEMINI 18






SEVROLL®



Handle length = door height		
LINE ARTE GM		
Handle Arte GM  anti-dust brush (inserted) 4.8 mm x 13 mm textile door stop (inserted) 14 mm x 4 mm		Guiding carriage GM18 Frame asymmetrical 
door height - h	$h = H - 40 \text{ mm}$	
door wing height with soft-close fitted	Mini SV25/40/60 SV-25/50	$h = H - 40 \text{ mm}$
	Top SV60/80, Central SV25/40	$h = H - 44 \text{ mm}$
board height - hb	$hb = h - 64 \text{ mm}$	
door width - w	$w = (W - 3 \text{ mm} + Z) : N$	
board width - wb	$wb = w - 32 \text{ mm}$	
lower horizontal profile length - L	$L = U = w - 48 \text{ mm}$	
upper horizontal profile length - U		
mirror height - hm	$hm = hb$	
mirror width - wm	$wm = wb - 4 \text{ mm}$	

number of doors - N	2	3	4	5
total overlap - Z	36 mm	72 mm	108 mm	144 mm

visual design – 4 wings	
	$w = (W - 3 + 108) : 4$
	$w = (W : 2 + 33) : 2$




Installation method for fitting 18 mm board (diag. A) and 4 mm mirror or glass (diag. B)

- with handle

- with upper profile

- with lower profile

**ATTENTION!**

Mirror (4 mm) should be used with a safety backing film. Safety glass (4.5 mm) comprises of two thin layers with a film in-between. Both mirror and glass need fitting gaskets U 18.

ATTENTION!

Remove protective film from aluminium elements (handles, tracks, connectors, etc.) prior to cutting them to the desired size. Film removal will reveal quality issues (eg. scratches)