





Opening dimensions



**Door leaf dimensions - #18 mm board**

Tracks <b>SMART</b> (top/bottom) door height - h	$h = H - 13 \text{ mm}$
Tracks <b>HIDE M.</b> (top/bottom) door wing height - h	$h = H - 10 \text{ mm}$
Board height (1 mm ABS edging) - hp	$hp = h - 2 \text{ mm}$
Door wing width - d	$d = (D + Z) : N$
Board width (1 mm ABS edging) - dp	$dp = d - 2 \text{ mm}$

Number of door wings - N	2	3	4	5
Total overlap - Z	30 mm	60 mm	90 mm	120 mm



Front – 4 wings	
	$w = (W + 90) : 4$
	$w = (W : 2 + 30) : 2$

**UWAGA!**

*When cutting the board, you need to include the thickness of ABS edging.  
1mm ABS edging was used for our calculation*

**ATTENTION!**  
System SMART can be used in conjunction with any of SEVROLL's handle profiles suitable for 18 mm fillings.

**HI-TEC stopper installation**



**ATTENTION!** Remove protective film from aluminium elements (handles, tracks, connectors, etc.) prior to cutting them to the desired size. Film removal will reveal quality issues (eg. scratches)