






Max. weight of 40 kg per two wings (2 x 20 kg)

Door filling 18 mm board



ATTENTION!
Dependent on customer needs, there are sets suitable for either left or right hinged doors



COMPONENTS

Set for folding doors Line - left or right

Top carriage	Bottom carriage	Clip hinge	Hinge	
				screws 3.5x16 (hinges, carriages) - 26 pcs
		X5	X4	screws 4x16 (hinges) - 24 pcs
				screws 3x13 (guiding tracks) - 12 pcs
				screws 2.5x16 (handle) - 30 pcs





LINE


DS SLIM LINE /

SYSTEM

DS LINE



Dimensions of opening







door height	- hw	$hw = H - 6 \text{ mm}$
board height	- hb	$hb = hw - 6 \text{ mm}$
door wing width	- ww	$ww = (W - 6 \text{ mm}) : 2$
board width	- wb	$wb = ww - 6 \text{ mm}$

Max. weight for 1 wing - 20 kg

The weight of 1m² of 18 mm board = 13 kg

Mounting position of hinge seat





LINE


DS SLIM LINE / DS LINE


SYSTEM

SEVROLL®

Method for positioning carriages and hinge recesses

The drawing below shows an alternative method
(when it is not possible to cut 35 mm openings in the aluminium profiles)






The assembly of folding doors **SLIM LINE** opened to the right and to the left side requires the use of two sets:

1. Set LINE (right side)
2. Set LINE (left side)

Dimensions of opening



door height	- hw	$hw = H - 6 \text{ mm}$
board height	- hb	$hb = hw - 6 \text{ mm}$
door wing width	- ww	$ww = (w - 7 \text{ mm}) : 4$
board width	- wb	$wb = ww - 6 \text{ mm}$