













**COMPONENTS**

<p><b>Handle EKONOMIK</b></p> <p>L: 2.70 m</p> <p>textile door stop (inserted) 4.8 mm x 4 mm</p> 	<p><b>Top track EKONOMIK</b></p> <p>L: 2.00 m, 3.00 m, 6.00 m</p>  <p>80</p>	<p><b>Bottom track EKONOMIK</b></p> <p>L: 2.00 m, 3.00 m, 6.00 m</p>  <p>50</p>	<p><b>Horizontal profile Ekonomik</b></p> <p>L: 2.00 m, 3.00 m, 6.00 m</p> 	<p><b>Screws</b></p> <p> Toothed washer 3 x 6 Fastening of carriages</p> <p> Self-tapping screw with washer head 2.9 x 6.5 Fastening of carriages</p> <p> Countersunk screw 3 x 16 Fastening of tracks</p> <p> Dome head screw 3x10 Fastening of handle (with chipboard filling)</p>
<p><b>Bottom carriage EKONOMIK</b></p> 	<p><b>Top carriage EKONOMIK</b></p> 	<p><b>Covering strip</b></p> 		

Dimensions of opening






**ATTENTION!**  
Mirror (4 mm) must be used with a safety backing film.

door filling - 10 mm board, 4 mm mirror

door height	- h	$h = H - 32 \text{ mm}$
board height	- hb	$hb = h - 2 \text{ mm}$
door width	- w	$w = (W - 3 \text{ mm} + Z) : N$
board width	- wb	$wb = w - 2 \text{ mm}$
horizontal profile length	- L	$L = w - 48 \text{ mm}$
mirror height	- hm	$hm = hb - 4 \text{ mm}$
mirror width	- wm	$wm = wb - 4 \text{ mm}$


number of doors	- N	2	3
total overlap	- Z	25 mm	50 mm

visual design - 4 wings	
	$w = (W + 72) : 4$
	$w = (W : 2 + 22) : 2$




Installation method for fitting 10 mm board (diag. A) and 4 mm mirror or glass (diag. B)


- with handle Ekonomik



- top carriage



- bottom carriage



**ATTENTION!** Remove protective film from aluminium elements (handles, tracks, connectors, etc.) prior to cutting them to the desired size. Film removal will reveal quality issues (eg. scratches)