


Dimensions of opening




handle length = door height

door filling - # 18 board

door height	- h		h = H - 42 mm		
door wing		Mini S SV-25	SV25/40/60 5/50	h = H - 42 mm	
height with soft-close fitted			V60/80, al SV25/40	h = H - 44 mm	
board height	- hb		hb = h - 2 mm		
door width	- w		w = (W - 3 mm + Z) : N		
board width	- wb		wb = w - 6 mm		
angle section length	- la		la = w - 16 mm		

number of doors	- N	2	3	4	5
total overlap	- Z	25 mm	50 mm	75 mm	100 mm

visual design – 4 wings				
door set up	w = (W - 3 + 75) : 4			
door set up	w = (W : 2 + 22) : 2			




ATTENTION! -


Handle profile should be 2 mm longer than board height.


- When fitting handle profiles, do not use assembly adhesive

Installation method for profile Slim Line and guiding carriage with # 18 mm board



Installation method for angle section 11 mm x 17 mm





WARNING

SEVROLL does not bear any responsibility for deformation resulting from the application of improper quality of boards (improper storage, improper humidity)